



How to use Sbworkshop,be2works adapter

- part support EEPROM
- 1 24C01A 24C02A 24C04A 24C046 (8 DIP 8 SOIC @) 01N 02M (MSOP)
 - 2 25XX040 (8 DIP . 8 SOIC @)
 - 3 93C6X P 93C6XSN (8 DIP) 93C6XST (8 TSSOP #)
S-29L130ADFE S-29L220ADFE(93C56) S-29L330ADFE (8 SOIC @)
S-29L130AFS S-29L220AFS(93C56) S-29L330AFS (8 SSOP #)
AK93C45AV AK93C55AV AK93C65AV AK93C75AV AK93C76 AK93C66(8 TSSOP #) L66(BPS2C)
S-2 9190ADPX S-29290ADPX S-29390ADPX (8 DIP)
 - 4 S-29L194ADFE S-29L294ADFE S-29L394ADFE (8 SOIC @)
S-29L194AFS S-29L294AFS S-29L394AFS (8 SSOP #)
AK6420AM AK6440AM AK6480AM (8 SSOP #)
BR9010 BR9020 BR9040 (8 SOIC @)
 - 5 AK6420AF AK6440AF AK6480AF (8 SOIC @)
BR9010F BR9010FV BR9020F BR9040F (8 SOIC @)
AK93C45AF AK93C55AF AK93C65AF (8 SOIC @)
S-29190AFJX S-29290AFJX S-29390AFJX (8 SOIC @)
S-29L130AFE S-29L220AFE S-29L330AFE (8 SOIC @)

NOTE :

- 1,mark "@" need "SOIC to DIP" , all mark "#" need "SSOP/TSSOP to DIP" help
- 2,one time just one part connet the EEPROM.
- 3,total 5 part "pin1" is





Unlock laptop battery chip tools

For laptop battery refill recell repair

P.S.: Need anything about laptop battery ,laptop part, please email me:xitonghan@139.com

We are in Haqiang Shenzhen China